



## ARRI TECHNICAL NOTE P - 1012

### Opening the 435 Movement

#### Summary

This note describes why the 435 movement should not be opened while the camera is running.

#### **Don't Open the 435 Movement Before the Camera has Completely Stopped!**

After the RUN button is pushed to stop the 435 from running, the camera will briefly run at 1 fps to place the mirror shutter in the correct viewing position. Under no circumstance should the movement be opened until it has come to a complete stop. Otherwise the movement could be damaged.

#### **New EPROM**

As a further precaution, all new EPROMs for the 435, starting with EPROM 1.34, will cut the power to the motor as soon as the movement is opened. For upgrade information, contact your local ARRI representative.

---

#### **Cross Reference**

- None

#### **Article Change History**

May 11, 1998      Article was created.

#### **Keywords**

435, Movement

For more information on this issue, please contact your local ARRI representative.